

Install of Redline Goods Shift Boot and Emergency Brake Boot for 1991 – 1998 Suzuki Cappuccino

1. Open the storage box in the middle of the console. Lift up the rubber insert; remove the 2 screws from the base.



2. Remove 2 front screws on either side of the console, just below the shifter.



3. Lean both seats forward, remove 2 rear screws on back of the console, on side by the roof opening mechanism.



4. Remove the shift knob.
5. Loosen the Velcro on the emergency brake boot to allow it to slip over the handle.



6. Gently pull on either side of the console and lift straight up, do not pull all the way just enough to loosen it from the transmission tunnel.
7. Slide the red button and pull up the roof handle on the back of the console; this allows the console to slip off easier. Lift the back of the console off, do not pull out all the way but lay it on its side on the driver's seat to access the connectors.



8. Disconnect the connector for the window controls, and disconnect the connector for the interior light.



9. Pull off the console and flip over to access the bottom, lay console on something soft so as not to scratch the console while you remove the boots.



10. The shift boot is held on by 4 circle fasteners, use flat head screwdriver to gently pry these off of the plastic, work around each side until the circle fastener is removed. Repeat on 3 other fasteners.



11. The emergency brake boot is held by 3 circle fasteners and a metal bracket. Using the same method as step 11, remove the 3 circle fasteners. No need to remove the metal bracket, push bottom of shift boot off the bracket and remove.



12. To install shift boot, place new shift boot in place and push plastic guides through each hole, fasten down with the circle fasteners. Push down the circle fasteners with a flat head screwdriver to ensure they are properly seated.



13. Extract the mounting bracket from the stock e-brake boot (cut it off). Slide it into the sewn hems on the bottom of the RedlineGoods shift boot, and glue the leather around the bracket on the side that has no pre-sewn hem. Use Contact Cement, Automotive GOOP or any other epoxy-based glue.
14. To install emergency brake boot, place boot in place, push the side that meets the metal bracket under the bracket, line up the plastic guides, and install the circle fasteners so the boot is sandwiched between the console and the fasteners.



15. Lay console on its side next to the transmission tunnel and reconnect the connector for the window and interior light controls.



16. Tilt console back, and lift the roof latch so that it slips onto the console.
17. Loosen the Velcro on the new emergency brake handle.

18. Gently guide the shifter and the emergency brake handle through the new boots. Push down on the console until it seats properly.



19. Replace 2 screws on the front of the console, 2 screws on the rear of the console, and 2 screws in the storage compartment. Replace rubber mat in the storage compartment.
20. Reinstall the shift knob, pull the emergency brake boot down and close Velcro.

