

Hurst B4 Shifter Boot Installation

Time: < 30 minutes

Step 1:
Unscrew shifter knob



Step 2:
Unscrew consol cover screws (2), remove ash tray, and unscrew ash-tray bezel screws (2)



Step 3:
Remove ash-tray bezel and disconnect cigarette lighter wiring



Step 4:
Remove consol cover, and remove existing shifter boot trim plate and nuts (4)



Step 5:

Lay the new RedlineGoods shifter boot in place being sure that the edge of the shifter boot is pulled to the corners and will be held by the trim plate. (I used blue masking tape to hold it in position)



Step 6:
Reinstall the trim plate and nuts (4).



Step 7:

Install the consol over the shifter. If desired you can do a reverse of the boot and fasten it to the shifter with a zip tie. (I did not do this because for shows I want to be able to quickly change to the OEM boot and it looked fine as is)



Step 8:

Reinstall all the consol and ash tray screws and connect the cigarette lighter wiring



Step 9:

Install the shifter ball and you are finished.

