

Covering the MX-5 ND center console with RedlineGoods leather:

1. Remove center console from car
 - 1a. Remove shift knob
 - 1b. Remove shifter surround trim
 - 1c. Unscrew two screws at forward end of console
 - 1d. Pull command module sharply at both ends to release clips
 - 1e. Carefully turn command module over and release plug
 - 1f. Pull sharply on both sides at the forward end, then both sides at the rear end to release clips
 - 1g. Guide parking brake boot over end of lever and remove
 - 1h. Remove parking brake boot from console
 - 1i. Turn console over and remove armrest/storage box by unscrewing silver screw on the bottom. Set armrest box aside.



2. Clean center console with alcohol and let dry

3. Paint center console and underside of leather with contact cement such as Weldwood. Allow to dry until both sides are tacky (10-15 minutes)



4. Carefully align leather with console and press into place. Stretch gently as you go to prevent wrinkles and misalignment.

5. Cut leather at cupholder hole as shown. Do not cut all the way to the edge. The leather will stretch over the console at the hole.



6. Cut small wedges as needed to fit leather around obstructions under the console and allow it to fold over the edges neatly.



7. Turn console over and trim excess. Leave enough leather to fold over the edges underneath.



8. Apply contact cement to underside of console and leather edges as needed. Allow to dry until tacky.



9. Carefully go around the underside of the console, sticking leather down and trimming where necessary for a neat job without bulk.



10. Reattach armrest/storage box and parking brake boot.



11. Align console clips and press down firmly until they click
12. Plug in command module and re-install
13. Replace two screws at forward end of console
14. Replace shifter trim
15. Replace shift knob. ENJOY!

